# Instructions

# For

## **Dixon Bayco**

### FT451 Ground Bolt Installation

#### For Sales and Service Contact

USA:

Dixon Bayco USA Chestertown, Maryland Phone: 410-778-2000 Fax: 410-778-4702

Toll Free: 800-355-1991

E-mail: dixonbayco@dixonvalve.com

Europe:

Dixon Group Europe Ltd Preston, England

Phone: +44 (0)1772 323529 Fax: +44 (0)1772 314664

E-mail: enquiries@dixoneurope.co.uk

Mexico:

Dixva, S. de R.L. de C.V. Monterrey, N.L

Monteney, N.L

Phone: 01-800-00-DIXON (34966)

Fax: 01-81-8354-8197

E-mail: contactenos@dixonvalve.com.mx

Canada:

Dixon Group Canada Limited Innisfil (Barrie), Ontario Phone: 705-436-1125 Fax: 705-436-6251 Toll Free: 877-963-4966

E-mail: isales@dixongroupcanada.com

Asia Pacific:

Dixon (Asia Pacific) Pty Ltd Wingfield,

South Australia

Phone: +61 8 8202 6000 Fax: +61 8 8202 6099

E-mail: enquiries@dixonvalve.com.au



The Right Connection\*

dixonvalve.com

#### FT451 Ground Bolt Installation

#### Installation

This procedure is for the installation of the FT451 Self Proving Grounding Ball.

- 1. Find a clear location on the trailer main frame support that is within reach of the rack grounding cable. This area is normally near the overfill sockets. Drill a 17/32" hole in the middle area of the frame support. Remove all sharp edges and clean the surface area around the hole.
- 2. Drill a  $\frac{1}{1}$ " hole approximately 4.0" to the left or right of the  $\frac{17}{32}$ " hole. Clean the area around the  $\frac{1}{1}$  drilled hole.
- 3. Crimp the eyelet on the end of the green wire.
- 4. Mount the ground ball in the 17/32" hole with the round end facing the outside of the trailer. The round ball end is where the rack ground plug is to connect.
- 5. Fasten the green wire by bolting the eyelet to the frame through the  $\frac{1}{2}$ " hole, using the  $\frac{1}{2}$ " bolt, lock washer, and nut.
- 6. Apply a small amount of grease on both the  $\frac{1}{2}$ " and  $\frac{1}{4}$ " nuts to block moisture from effecting continuity.

Do not use electric drills or tools that generate heat, sparks, or use electricity near a petroleum tanker unless the tank has been purged of flammable gases.

#### **Dixon Bayco Warranty**

For complete warranty information, please refer to the latest Dixon catalog.